Kodel Number

Dimensions


Technical Data

NCB2-12GM35-N0

Features


- 2 mm embeddable
- Usable up to SIL2 acc. to IEC 61508





	_	_	_	_	_	_		
А	C	C	е	S	S	U	r I	es

EXG-12 Quick mounting bracket with dead stop BF 12 Mounting flange, 12 mm



General specifications Switching element function NAMUR, NC Rated operating distance Installation s_n 2 mm embeddable Output polarity NAMUR Assured operating distance Reduction factor r_{Al} 0 ... 1.62 mm 0.23 Sa Reduction factor r_{Cu} 0.21 Reduction factor r₃₀₄ 0.7 Nominal ratings Nominal voltage 8.2 V (R_i approx. 1 kΩ) Uo Switching frequency 0 ... 1000 Hz f H 1 ... 10 typ. 3 % Hysteresis Reverse polarity protected reverse polarity protected Short-circuit protection yes yes, Reverse polarity protection diode not required Suitable for 2:1 technology Current consumption Measuring plate not detected \geq 3 mA Measuring plate detected ≤ 1 mA Indication of the switching state all direction LED, yellow Ambient conditions -25 ... 100 °C (-13 ... 212 °F) -40 ... 100 °C (-40 ... 212 °F) Ambient temperature Storage temperature Mechanical specifications cable PVC , 2 m Connection type Core cross-section 0.34 mm² Housing material Stainless steel 1.4305 / AISI 303 Sensing face Protection degree PBT IP66 / IP67 General information Scope of delivery Use in the hazardous area 2 self locking nuts in scope of delivery see instruction manuals 1G; 2G; 3G; 1D; 3D Category Compliance with standards and directives Standard conformity EN 60947-5-6:2000 NAMUR IEC 60947-5-6:1999 NE 21:2007 Electromagnetic compatibility EN 60947-5-2:2007 Standards IEC 60947-5-2:2007 Approvals and certificates FM approval Control drawing 116-0165F UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose CCC approval Products with a maximum operating voltage of \leq 36 V do not bear a CCC marking because they do not require approval.

Subject to modifications without notice

Pepperl+Fuchs Group USA: +1 330 4 www.pepperl-fuchs.com fa-info@us.pepper

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

ATEX 1G	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G	
Directive conformity	for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2006, EN 60079-11:2007, EN 60079-26:2007
Standard conformity	Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0102$
CE symbol	C C0102
Ex-identification	🐼 II 1G Ex ia IIC T6
EC-Type Examination Certificate	PTB 00 ATEX 2048 X
Appropriate type	NCB2-12GMN0
Effective internal capacitance Ci	\leq 90 nF ; a cable length of 10 m is considered.
Effective internal inductance L _i	\leq 100 μH ; a cable length of 10 m is considered.
Cable length	Dangerous electrostatic charges on the fixed connection cable must be taken into account for lengths equal to and exceeding the following values:
Explosion group IIA	100 cm
Explosion group IIB	50 cm
Explosion group IIC	8 cm
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.
Highest permissible ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2006, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0.002$

🐼 II 1G Ex ia IIC T6

PTB 00 ATEX 2048 X

NCB2-12GM ...- N0 ...

 \leq 90 nF ; a cable length of 10 m is considered.

 \leq 100 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the per-

missible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^\circ C$ the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Subject to modifications without notice Pepperl+Fuchs Group

repperi+Fuchs Group USA: +1 330 www.pepperi-fuchs.com fa-info@us.pepp

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



ATEX 1D

Instruction

Device category 1D Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Special conditions

Electrostatic charging

for use in hazardous areas with combustible dust 94/9/FG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions **C**€0102

(Ex) II 1D Ex iaD 20 T 108 °C (226.4 °F) The Ex-significant identification is on the enclosed adhesive label

ZELM 03 ATEX 0128 X NCB2-12GM...-N0...

 \leq 90 nF ; a cable length of 10 m is considered.

 \leq 100 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. The intrinsically safe circuit has to be protected against influences due to lightning.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use

Subject to modifications without notice USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



ATEX 3D	
Note	This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with non-conducting combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 50281-1-1 Protection via housing Use is restricted to the following stated conditions
CE symbol	C € 0102
Ex-identification	(${\rm E}$) II 3D IP67 T 109 °C (228.2 °F) X The Ex-significant identification is on the enclosed adhesive label
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Minimum series resistance R_V	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage U _{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum heating (Temperature rise)	Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U _{Bmax} =9 V, R _V =562 Ω	9 K
using an amplifier in accordance with EN 60947-5-6	9 K
Protection from mechanical danger	The sensor must not be mechanically damaged.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

 Subject to modifications without notice

 Pepperl+Fuchs Group
 US

 www.pepperl-fuchs.com
 fa-info



ATEX 3D (tD)	
Note	This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with non-conducting combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD"
	Use is restricted to the following stated conditions
CE symbol	C € 0102
Ex-identification	⟨͡ᢑ⟩ II 3D Ex tD A22 IP67 T80°C X
	The Ex-relevant identification may also be printed on the accompanying adhesive label.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip- ment.
	The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	The statutory requirements, directives and standards applicable to the intended use and application must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Minimum series resistance R_{V}	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage U _{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum permissible ambient tempera- ture T _{Umax}	Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U _{Bmax} =9 V, R _V =562 Ω	61 °C (141.8 °F)
using an amplifier in accordance with EN 60947-5-6	61 °C (141.8 °F)
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

ATEX 3G (nL)

Instruction

Device category 3G (nL) Directive conformity Standard conformity

CE symbol

Ex-identification

Effective internal capacitance Ci Effective internal inductance Li

General

Installation, Comissioning

Maintenance

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW li=25 mA T5 for Pi=34 mW, li=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, li=25 mA, T5 for Pi=64 mW. li=25 mA. T4-T1 for Pi=169 mW. li=52 mA. T6 for Pi=169 mW, li=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, li=76 mA, T6 for Pi=242 mW, li=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1 Protection from mechanical danger

Protection from UV light

Electrostatic charging

Protection of the connection cable

Connection parts

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions € € 0102

(x) II 3G Ex nL IIC T6 X The Ex-significant identification is on the enclosed adhesive label

 \leq 90 nF ; a cable length of 10 m is considered. \leq 100 μH ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions.

If the equipment is not used under atmospheric conditions, a reduction of the per-missible minimum ignition energies may have to be taken into consideration.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-15. The explosion group depends on the connected and energy-limited supply circuit.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible

55 °C (131 °F)
55 °C (131 °F)
52 °C (125.6 °F)
52 °C (125.6 °F)
52 °C (125.6 °F)
44 °C (111.2 °F)
44 °C (111.2 °F)
44 °C (111.2 °F)

The sensor must not be exposed to $ANY\,FORM$ of mechanical danger. When used in the temperature range below -20 $^\circ C$ the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cable must be prevented from being subjected to tension and torsional loading.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Subject to modifications without notice Pepperl+Fuchs Group

USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



ATEX 3G (ic) Instruction

Device category 3G (ic)

Directive conformity Standard conformity

CE symbol

Ex-identification

 $\begin{array}{l} \mbox{Effective internal capacitance } C_i \\ \mbox{Effective internal inductance } L_i \end{array} \end{array}$

General

Installation, Comissioning

Maintenance

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6

- for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T4-T1
- for Pi=242 mW, li=76 mA, To
- for Pi=242 mW, li=76 mA, T4-T1
- Protection from mechanical danger

Electrostatic charging

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist $\ensuremath{94/9/\text{EG}}$

EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions

 $\overleftarrow{\mbox{k}}$ II 3G Ex ic IIC T6 X The Ex-significant identification is on the enclosed adhesive label

 \leq 90 nF ; a cable length of 10 m is considered.

 \leq 100 μ H ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11.

The explosion group complies with the connected, supplying, power limiting circuit. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

 $\begin{array}{c} 55 \ ^\circ C \ (131 \ ^\circ F) \\ 55 \ ^\circ C \ (131 \ ^\circ F) \\ 55 \ ^\circ C \ (131 \ ^\circ F) \\ 55 \ ^\circ C \ (131 \ ^\circ F) \\ 55 \ ^\circ C \ (131 \ ^\circ F) \\ 55 \ ^\circ C \ (131 \ ^\circ F) \\ 52 \ ^\circ C \ (125.6 \ ^\circ F) \\ 52 \ ^\circ C \ (125.6 \ ^\circ F) \\ 52 \ ^\circ C \ (125.6 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 44 \ ^\circ C \ (111.2 \ ^\circ F) \\ 45 \ ^\circ C \ (111.2 \$

The sensor must not be mechanically damaged. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

