



| Technical Data | | |
|-----------------------------------|----------------|--|
| General specifications | | |
| Switching element function | | NAMUR, NC |
| Rated operating distance | s _n | 5 mm |
| Installation | | embeddable |
| Output polarity | | NAMUR |
| Assured operating distance | sa | 0 4.05 mm |
| Reduction factor r _{Al} | | 0.21 |
| Reduction factor r _{Cu} | | 0.18 |
| Reduction factor r ₃₀₄ | | 0.63 |
| Nominal ratings | | |
| Nominal voltage | Uo | 8.2 V (R_i approx. 1 k Ω) |
| Operating voltage | UB | 5 25 V |
| Switching frequency | f | 0 500 Hz |
| Hysteresis | Н | 3 % |
| Current consumption | | ≥3 mA |
| Measuring plate not detected | | < 1 mA |
| Measuring plate detected | | S I IIIA |
| Ambient conditions | | |
| Ambient temperature | | -25 100 °C (-13 212 °F) |
| Mechanical specifications | | |
| Connection type | | Device connector M12 x 1, 4-pin |
| Housing material | | Stainless steel 1.4305 / AISI 303 |
| Sensing face | | PBT |
| Protection degree | | IP67 |
| General information | | |
| Use in the hazardous area | | see instruction manuals |
| Category | | 1G; 2G |
| Compliance with standards and dir | ectives | |
| Standard conformity | | |
| NAMUR | | EN 60947-5-6:2000 |
| | | IEC 60947-5-6:1999 |
| Standards | | EN 60947-5-2:2007 |
| | | IEC 60947-5-2:2007 |
| Approvals and certificates | | |
| FM approval | | |
| Control drawing | | 116-0165F |
| UL approval | | cULus Listed, General Purpose |
| CSA approval | | cCSAus Listed, General Purpose |
| CCC approval | | Products with a maximum operating voltage of \leq 36 V do not bear a |
| | | CCC marking because they do not require approval. |
| | | |
| | | |
| | | |

Subject to modifications without notice Pepperl+Fuchs Group USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

www.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

776-4411 Singaj

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



| ATEX 1G | |
|---|---|
| Instruction | Manual electrical apparatus for hazardous areas |
| Device category 1G | |
| Directive conformity | for use in hazardous areas with gas, vapour and mist 94/9/EG |
| | |
| Standard conformity | EN 60079-0:2006, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions |
| CE symbol | CE0102 |
| Ex-identification | € II 1G Ex ia IIC T6 |
| EC-Type Examination Certificate | PTB 00 ATEX 2048 X |
| Appropriate type | NJ 5-18GM-N |
| Effective internal capacitance C _i | \leq 70 nF ; a cable length of 10 m is considered. |
| Effective internal inductance Li | $\leq 50 \; \mu H$; a cable length of 10 m is considered. |
| General | The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration. |
| Highest permissible ambient temperature | The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1. |
| Installation, Comissioning | Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appro- priate related apparatus and according to the proof of intrinsic safety. The associa- ted apparatus must satisfy the requirements of category "ia" and have electrical isolation between the power supply and signal circuits. The sensor must be protected from strong electromagnetic fields. |
| Maintenance | No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. |
| Special conditions | |
| Protection from mechanical danger | When used in the temperature range below -20 $^\circ\mathrm{C}$ the sensor should be protected from knocks by the provision of an additional housing. |
| Electrostatic charging | Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. |

776-4411 Singapor

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2006, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0.002$

🐼 II 1G Ex ia IIC T6

PTB 00 ATEX 2048 X

NJ 5-18GM-N...

 \leq 70 nF ; a cable length of 10 m is considered.

 \leq 50 μ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the per-

missible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The sensor must be protected from strong electromagnetic fields.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^\circ C$ the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Subject to modifications without notice Pepperl+Fuchs Group

Pepperl+Fuchs Group USA: +1 330 www.pepperl-fuchs.com fa-info@us.pepp

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



3